

**SWAGELESS EYE TERMINALS**

[Assemble Instructions](#)

[download pdf \(50 Kb.\)](#)

High Polished Stainless Steel - AISI 316



Cat. No.	A	L1 (mm.)	L2 (mm.)	D1 (metr.) (mm.)	D1 (inch.)	D2 (mm.)	KW (mm.)	KW1 (mm.)	Break Load (metr.) (Kg.)	Break Load (inch) (Kg.)
821903	5,5	50	58	3	-	6,3	10	12	750	-
821932	5,5	50	58	-	1/8"	6,3	10	12	-	750
821904	7	58	68	4	5/32"	8,3	13	14	1.500	1.500
821947	8	70	81	-	3/16"	10,3	14	16	-	2.150
821905	8	70	81	5	-	10,3	14	16	2.180	-
821955	9	83	97	-	7/32"	12,3	17	19	-	3.000
821906	9	83	97	6	-	12,3	17	19	3.700	-
821963	9	83	97	-	1/4"	12,3	17	19	-	3.700
821907	9	89	105	7	9/32"	12,3	18	22	4.700	4.700
821908	10	103	121	8	5/16"	14,3	19	24	5.600	5.600
821995	13	116	135	-	3/8"	16,3	24	27	-	8.000
821910	13	116	135	10	-	16,3	24	27	8.300	-
821912	15	137	160	12	-	19,5	27	32	12.000	-
821913	15	137	160	-	1/2"	19,5	27	32	-	13.600
821914	18	159	185	14	-	22,5	32	36	17.000	-
821916	20	180	210	16	-	22,5	36	41	23.000	-

Note: All breakloads are determined by wedges (jaws) and eye (D2).  
The user is responsible for choosing the proper cable diameter and for correct assembly.

[back](#)



Buscarons, 6 - 08022 Barcelona | Tel.: (+34) 934 186 632 | Fax: (+34) 934 185 648  
E-Mail: [info@allrig.net](mailto:info@allrig.net) | [www.allrig.net](http://www.allrig.net)