

SWAGELESS FORK TERMINALS

Assemble Instructions

download pdf (50 Kb.)

High Polished Stainless Steel - AISI 316



Cat. No.	A (mm.)	L1 (mm.)	L2 (mm.)	L3 (mm.)	D1 (metr.)	D1 (inch.)	D2 (mm.)	KW (mm.)	KW1 (mm.)	Break Load (metr.) (Kg.)	Break Load (inch.) (Kg.)
840603	6	55	63	8	3	-	6	14	12	750	-
840632	6	55	63	8	-	1/8"	6	14	12	-	750
840804	8	62	73	8	4	5/32"	8	19	14	1.500	1.500
841047	10	72	83	10	-	3/16"	10	22	16	-	2.150
841005	10	72	83	10	5	-	10	22	16	2.180	-
841255	12	82	95	12	-	7/32"	12	27	19	-	3.000
841206	12	82	95	12	6	-	12	27	19	3.700	-
841263	12	82	95	12	-	1/4"	12	27	19	-	3.700
841207	12	102	115	13	7	9/32"	12	29	22	4.700	4.700
841408	14	103	118	14	8	5/16"	14	30	24	5.600	5.600
841695	16	117	135	16	-	3/8"	16	36	27	-	8.000
841610	16	117	135	16	10	-	16	36	27	8.300	-
841912	18	142	162	16	12	-	19	42	32	12.000	-
841913	18	142	162	16	-	1/2"	19	42	32	-	13.600
842214	21	162	190	19	14	-	22	46	36	17.000	-
842516	23	184	217	22	16	-	25	55	41	23.000	-

Note: All breakloads are determined by wedges (jaws) and clevis pin .
The user is responsible for choosing the proper cable diameter and for correct assembly.

back



Buscarons, 6 - 08022 Barcelona | Tel.: (+34) 934 186 632 | Fax: (+34) 934 185 648
E-Mail: info@allrig.net | www.allrig.net